Hejnar PHOTO

ARCA STYLE QUICK RELEASE MOUNTING SYSTEM

Mounting Conversion Plate to Manfrotto MHXPRO-3WG





Remove Level Screw with Torx Wrench (provided). Nut on opposite side may have to be hold in place with any small object to prevent rotating





Remove Level and Safety stop mechanism.



Remove Pin from safety mechanism and save it. You will need it later in step 6.

4



Place adapter plate at top of Manfrotto head.



Attached adapter plate with M5 screw using opening in a Manfrotto head where level screw was located. Use provided Nut in place of original Nut removed in step 1 8



Rotate head to its original working orientation and attached arca clamp. Clamp can be mount in 4 different orientation.



Place pin removed in step 3 in original position. We you will use it as second holding point.

9

6

You are now complete and can begin to use your equipment.



Attach button screw. Screw will rest on the pin. Use long ball point hex L key